

MANUAL FOAM SOAP DISPENSER INSTALLATION

A Packing List

* we have different shape but same installation.

B Part Name

Different Pump for Different Liquid
1. Spray: Sanitizer Liquid;
2. Soap: Gel or Soap Liquid;
3. Foam: Foam Liquid.

C Way for Screw

1. Drill hole (6mm Drill) and insert plug
2. fix screw

D Way for Sticker/without Screw

1. Double-sided adhesive* (Optional)
2. Silicone Sealant*

* The standard Packing is not including Double-sided adhesive and Silicone sealant

E Fill Liquid

F Enjoy hand sanitizing

Push to get Liquid

SENSOR FOAM SOAP DISPENSER INSTALLATION

A Packing List

* we have different shape but same installation.

B Part Name

* Different Pump for Different Liquid
1. Spray: Sanitizer Liquid;
2. Soap: Gel or Soap Liquid;
3. Foam: Foam Liquid.

C Height from Floor/Table

* keep away from sunshine and humid place

D Way for Screw

E Install Batteries/DC Adapter

DC Adapter * (6V1A, Optional)
4Pcs Batteries (1.5V*4Pcs, Size C) *

* The Standard Packing is not including DC Adapter and Batteries

F Installation with Adhesive Backing (no screws)

1. Double-sided adhesive* (Optional)
2. Silicone Sealant*

* The standard Packing is not including Double-sided adhesive and Silicone sealant

G Fill Liquid

H Enjoy hand sanitizing

• UV disinfection
• LED Light:
1. green color 5 seconds flush: working condition
2. red color 5 seconds flush: low power for batter and change;
3. red color 2 seconds flush: something under sensor and remove it;
• Sensing Distance: 8-12cm